


NOTE:
PLACE DISTAL PORT ASSEMBLY
AT END OF MAINFOLD FOR FLUSHING

FLOW EQUALIZATION PROCEDURE:

1. INSTALL CLEAR PIPE TO ADAPTER.
2. OPEN ALL VALVES.
3. TURN ON PUMP AND NOTE ELEVATION OF WATER IN EACH PIPE.
4. EQUALIZE HEIGHT FOR EACH WITH GATE VALVE AT START OF LATERAL.
5. AFTER EQUALIZATION, TURN OFF PUMP AND REMOVE PIPES. CLOSE VALVES AND REINSTALL CAPS.



DISTAL HEAD PORT

Geomatrix Systems, LLC.
114 Mill Rock Road E. Old Saybrook, CT
860-510-0730

SCALE	NONE	REV.	7/31/16
DATE	1/31/2010	ACAD No.	DISTAL HEAD PORT.DWG
DRAWN BY:	ERP	SHEET	1 OF 1